

Part Number for a complete sensor	Distance	Front or side sensing	Digital output	Output Mode	Markings for projector only half	Markings for detector only half
EX-11A	150mm	Front Sense	NPN	Light-on	EX-11P	EX-11AD
EX-11A-PN			PNP		EX-11P	EX-11AD-PN
EX-11B			NPN	Dark-on	EX-11P	EX-11BD
EX-11B-PN			PNP		EX-11P	EX-11BD-PN
EX-11EA		Side Sense	NPN	Light-on	EX-11EP	EX-11EAD
EX-11EA-PN			PNP		EX-11EP	EX-11EAD-PN
EX-11EB			NPN	Dark-on	EX-11EP	EX-11EBD
EX-11EB-PN			PNP		EX-11EP	EX-11EBD-PN

EX-13A	150mm	Front Sense	NPN	Light-on	EX-13P	EX-13AD
EX-13A-PN			PNP		EX-13P	EX-13AD-PN
EX-13B			NPN	Dark-on	EX-13P	EX-13BD
EX-13B-PN			PNP		EX-13P	EX-13BD-PN
EX-13EA		Side Sense	NPN	Light-on	EX-13EP	EX-13EAD
EX-13EA-PN			PNP		EX-13EP	EX-13EAD-PN
EX-13EB			NPN	Dark-on	EX-13EP	EX-13EBD
EX-13EB-PN			PNP		EX-13EP	EX-13EBD-PN

EX-19A	1 meter	Front Sense	NPN	Light-on	EX-19P	EX-19AD
EX-19A-PN			PNP		EX-19P	EX-19AD-PN
EX-19B			NPN	Dark-on	EX-19P	EX-19BD
EX-19B-PN			PNP		EX-19P	EX-19BD-PN
EX-19EA		Side Sense	NPN	Light-on	EX-19EP	EX-19EAD
EX-19EA-PN			PNP		EX-19EP	EX-19EAD-PN
EX-19EB			NPN	Dark-on	EX-19EP	EX-19EBD
EX-19EB-PN			PNP		EX-19EP	EX-19EBD-PN

EX-11SA	150mm	Front Sense	NPN	Light-on	EX-11SP	EX-11SAD
EX-11SA-PN			PNP		EX-11SP	EX-11SAD-PN
EX-11SB			NPN	Dark-on	EX-11SP	EX-11SBD
EX-11SB-PN			PNP		EX-11SP	EX-11SBD-PN
EX-11SEA		Side Sense	NPN	Light-on	EX-11SEP	EX-11SEAD
EX-11SEA-PN			PNP		EX-11SEP	EX-11SEAD-PN
EX-11SEB			NPN	Dark-on	EX-11SEP	EX-11SEBD
EX-11SEB-PN			PNP		EX-11SEP	EX-11SEBD-PN

EX-13SA	500mm	Front Sense	NPN	Light-on	EX-13SP	EX-13SAD
EX-13SA-PN			PNP		EX-13SP	EX-13SAD-PN
EX-13SB			NPN	Dark-on	EX-13SP	EX-13SBD
EX-13SB-PN			PNP		EX-13SP	EX-13SBD-PN
EX-13SEA		Side Sense	NPN	Light-on	EX-13SEP	EX-13SEAD
EX-13SEA-PN			PNP		EX-13SEP	EX-13SEAD-PN
EX-13SEB			NPN	Dark-on	EX-13SEP	EX-13SEBD
EX-13SEB-PN			PNP		EX-13SEP	EX-13SEBD-PN

EX-19SA	500mm	Front Sense	NPN	Light-on	EX-19SP	EX-19SAD
EX-19SA-PN			PNP		EX-19SP	EX-19SAD-PN
EX-19SB			NPN	Dark-on	EX-19SP	EX-19SBD
EX-19SB-PN			PNP		EX-19SP	EX-19SBD-PN